

MOUNTING LOCATION:
Upper right of dash cavity K UR

TOOLS REQUIRED:
Phillips screwdriver

PARTS INCLUDED:
(1) S7144-100 Mount

CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS

PART#: **75144-100**
MFG: **WESTERN STAR**
MODELS & YEARS:
SEMI - ALL 1996-2019

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

NOTE: Mounts taken off of older model trucks may need to enlarge the screw hole in mount to fit newer models.

- STEP #1 Remove (2) Phillips screws located on top of the right instrument panel located above the dashboard rocker switches.
- STEP #2 Pull woodgrain panel back approximately 2 inches on top. Panel is hinged on the bottom. Locate air vent at upper right-hand corner of panel.
- STEP #3 Slide InDash mount into right corner position and align outside hole of woodgrain panel hole and reassemble factory Phillips screw through panel and InDash Mount into threaded nut of dash.
- STEP #4 Attach phone holder to Mount.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW PANAVISE INDASH MOUNT.



Final install showing location



06-28-18