

### MOUNTING LOCATION:

Above Left of Radio JUL

### TOOLS REQUIRED:

Hook tool, Dash Tool

9/32" socket driver,

5/16" wrench, Soft Cloth

### PARTS INCLUDED:

(1)S751072313,(1)S75006TOP

(2)8-32" Acorn Nuts

### CELL PHONE & MEDIA MOUNT

### INSTALLATION INSTRUCTIONS

PART#:751072313

MFG: FORD

FORD-F250/350/450/550

2013-2016

(With 8" NAV Screen Only)

### \*\* ADVISEMENT \*\*

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Hook Tool/Dash Tool remove the (2) covers at the lower portion of the Radio/Climate control bezel. (Audio Input & Power Outlet) Insert Hook Tool into the slot at the bottom of these corners and pull to release (4) clips on each cover. Pull out covers and let hang down. With 9/32"(7mm) wrench, remove the (2) exposed screws.

STEP #2: To remove the large bezel assembly that includes Radio/Climate Control/Air Vent bezel, begin at the top by pulling with your hands to release the (6) clips at the top of the bezel. You may be able to install the InDash by PanaVise Mount at this time, Go To: STEP#3. Although if you need to continue to release the bezel including (6) more clips mostly positioned around the air vents, with (2) clips at the bottom of the bezel. Let bezel hang down to allow access to the left side set of vertical mounting screws at the top left of the screen.

STEP #3: Remove the (2)-9/32 vertical screws from the top left of the screen. Place the BOTTOM part of the InDash by PanaVise Mount over the screw holes and replace screws. Note direction in picture of mount.

STEP #4: Replace the radio bezel assembly starting at the bottom, be sure to align the tongue of the trailer control in the metal slot behind on the dash. There are many places where posts and pins need to be aligned to allow this bezel assembly to fit back on correctly.

STEP #5: Install the TOP part (75006) on to the BOTTOM with the (2) Acorn nuts using a 5/16" wrench.

INSTALLATION IS COMPLETE. ENJOY YOUR NEW INDASH BY PANAVISE MOUNT.



Removal of lower covers and



Location of Mounting Screws



Final Installation Picture



Bottom of mount in place showing location

09-22-2020

