

INDASH by PANAVISE®

751101614

Page 1 of 1

MOUNTING LOCATION:

Above Radio/Display JPRLU

TOOLS REQUIRED:

Dash Tool

7mm Socket Driver

PARTS INCLUDED:

(1) 751101614 Mount

(3) A-#8x9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 751101614

MFG: CHEVY / GMC

MODELS & YEARS:

CHEVY- 1500 Silverado 14-18

2500/3500HD Silverado 15-19

GMC - 1500 Sierra 14-18

2500/3500HD Sierra 15-19

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With Dash tool remove the bezel around the Radio, may include switches. There are (10) total clips that hold it in place.

STEP #2: Remove (1) of the upper dash screws with 7mm socket driver.

STEP #3: Place the InDash Mount slot over the screw hole. Replace the screw while pushing the mount up to be flush with the dash. Tighten the screw.

STEP #4: Install 2 of the 3 supplied screws into the holes to the sides of the mount.

STEP #5: Replace the bezel.



InDash installed showing location

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing Right mounting location



InDash installed showing Left mounting location

InDash installed showing Right and Left mounting location



06-28-18

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2018 PanaVise Products, Inc.